


9. THIRD STAGE SUCTION VALVE ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since improvement are made from time to time, the illustration and specifications are subject to change without notice.

9. SUCTION VALVE COVER ASSEMBLY (1ST STAGE)

No.	Description	Ref Part No.	QTY
-	Suction Valve Assembly	Z2593196	1
1	*Valve Seat Assembly	Z2589188	1
2	*Valve Keeper	C7176170	1
3	*Damper Plate	E2226170	1
4	*Valve Plate	-	1
5	*Spring Plate	-	4
6	*Lift Washer - Middle	H0899196	1
7	*Lift Washer - Upper	H0747170	1
-	*'O' Ring For Piston	H0210170	2
-	*'O' Ring For Valve Cover	H0212170	1
-	*Diaphragm	H1208188	1
-	*Copper Gasket	M3624170	1
-	Cylinder D 18		1
-	Push Rod For Regulation	B0960192	1
-	Spring For Lifter	H3477188	1
-	Protection Grill	A7536188	1
-	Diaphragm	H1209198	1
-	Suction Valve Service Kit	Z2595196	-