


## 4. SECOND STAGE AIR CYLINDER ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

## 4. SECOND STAGE AIR CYLINDER ASSEMBLY

No.	Description	Ref Part No.	QTY
1	220 cyl. Heads, Piston Assly.	Z1738163	1
-	Cylinder Dia. 220	B0352163	1
2	Outer Head D. 220	1901060308	1
3	*Gasket for Closing Plate	H0733151	1
4	*Closing Plate	B3613151	1
5	Air Cylinder Head Assembly (Inner)	Z1676164	1
6	Gasket between Cyl. Hd. And Cylinder	H0760162	2
7	Deflector	D9651163	1
8	'O' Ring for Deflector	H0215163	1
9	Grub Screw M5 x10	M2844150	2
10	Gasket between cyl. & Cyl. Hd. Inner	H0770163	2
11	Gasket for Gland Box	H0755162	1
12	Hex Hd. Screw M10x25	M2615150	8
13	Gland Box for Oil Wiper Ring	C6111162	1
14	Oil Wiper Ring (Pair)	H1445162	1
15	Soc. Hd. Screw M6*15	M2855150	4
16	Cover for Oil Wiper Ring	B7221162	1
17	Hex Hd. Screw M8x30	M2623150	4
18	Gasket for Cover	H0756162	1
19	Sealing Ring	H1446162	1
20	Cover for sealing Ring	B3861162	1
21	Gasket for Water Passage	H0786163	8
22	Packing Flange	C4482162	1
23	*Stuffing Box	B1807162	1
24	Sleeve	D9654165	1
25	*'O' Ring	H0216150	1
26	Outer Sleeve	D9653165	5
27	Intermediate Sleeve	D9654165	4
28	Packing ring with Spring	H1444162	10
29	Packing Sleeve	D9652165	1
30	Aluminium Washer	H0763150	1