


7. FIRST STAGE SUCTION VALVE ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

7. FIRST STAGE SUCTION VALVE ASSEMBLY

No.	Description	Ref Part No.	QTY
-	Suction Valve Assembly	Z2568196	1
1	*Valve Seat Assembly	Z2120196	1
2	*Valve Keeper Assembly	Z2122196	1
3	*Damper Plate	E2230196	2
4	* Valve Plate	-	1
5	* Valve Spring	-	8
6	* Lift Washer - Middle	H0809196	1
7	* Lift Washer - Upper	H0808196	1
8	*Split Pin	M5109170	1
-	*'O' Ring For Valve Cover	H0221170	1
-	*'O' Ring For Unloading Piston	H0210170	1
-	Topper Gasket	M3637170	1
-	Piston D 35	B0902196	1
-	Piston For Regulation	B0903196	1
-	Spring for Lifter	H3483196	1
-	Valve Cover	C0220164	1
-	Suction Valve Service Kit	Z2576196	1