

## 9. Auxiliary Valve - Model 9.5 x 7 LUB

| No. | Description              | Ref Part No. | QTY |
|-----|--------------------------|--------------|-----|
| 1   | Aux Valve Complete       | 48XXAIL      | -   |
| 2   | – Body-Aux Valve (B) (A) | 48XXA2AB     | 1   |
| 3   | – Bushing-Top Seat       | NSS          | 1   |
| 4   | – Valve-Aux              | 2W24013      | 1   |
| 5   | – Seat-Lower Seat        | XX4AL        | 1   |
| 6   | – Bushing-Lower Seat     | NSS          | 1   |
| 7   | – Adjuster-Spring        | XX5          | 1   |
| 8   | – Shim-Lower VA Seat     | XX14         | 20  |
| 9   | – Locknut-spr Adjuster   | XX15L        | 1   |
| 10  | – Spring                 | PP100        | 1   |
| 11  | – Guide-Spring           | XXA6         | 1   |
| 12  | – Nut-Hand Unloading     | A1120L       | 1   |
| 13  | – Screen & Ring          | XX13A        | 1   |

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.