



All manufacturer's names,numbers,photos,product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.



3. FIRST STAGE CYLINDER ASSEMBLY

No.	Description	Ref Part No.	QTY
1	Cylinder Assembly, Dia 320	Z1661196	1
-	Gasket for Door	H0730188	2
-	Cu. Washer	M3619170	20
2	Cylinder Head Assembly (Outer)	Z1767196	1
3	*Gasket For Closing Plate	H0733188	1
4	*Cu. Washer	M3619170	6
5	Cylinder Head Assembly (Inner)	Z1662196	1
6	*Stuffing Box	-	1
7	*'O' Ring	H0216170	2
-	*Sp. Washer	M3727170	4
8	Gasket For Cyl. Inlet & Outlet	H0806196	2
9	Deflector	D9651196	1
10	'O' Ring For Deflector	H0215170	1
11	Grub Screw IVIS X 10	M2844170	2
12	Oil Sealing Ring	H1446196	1
13	Oil Wiper Ring (Pair)	H1445196	1
-	Packing Ring Set (First Stage)	Z6803196	1
14	*Packing ring (Set of 2)	H1444196	6
15	Aluminium Washer	-	1
16	Packing Sleeve	-	2
17	Intermediate Sleeve	-	2
18	Outer Sleeve	-	3
19	Sleeve	-	1
20	Packing Flange	-	1
21	Helilock Nut	-	4