



5. SECOND & THIRD STAGE CYLINDER ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

5. SECOND & THIRD STAGE CYLINDER ASSEMBLY

No.	Description	Ref Part No.	QTY
1	Cylinder Assembly (Second Stage), Dia 220	Z1660196	1
-	Gasket For Door	H0730188	2
-	Cu. Washer	M3619170	20
2	Cylinder Head Assembly (Inner)	Z1676196	1
3	*Stuffing Box	-	1
4	*'O' Ring	H0216170	1
5	*'O' Ring	H0222170	1
-	*Sp. Washer	M3727170	4
6	Gasket For Cylinder Inlet	H0752162	1
7	Gasket For Cylinder Outlet	Y5837032	1
8	Cylinder Assembly (Third Stage), D 115	Z1686196	1
-	Gasket For Door	H0732188	2
-	Cu. Washer	M3619170	20
9	Cylinder Head (Outer)	Y5800250	1
-	Gasket (3rd. Stage Cyl. & Cyl. Head)	Y5806009	1
-	Gasket For Cyl. Inlet & Outlet	Y5837035	2
10	Deflector	D9651196	1
11	'O' Ring For Deflector	H0215170	1
12	Grub Screw M5 X 10	M2844170	2
13	Oil Sealing Ring	H1446196	1
14	Oil Wiper Ring (Pair)	H1445196	1
-	Packing Ring Set (Second & Third Stage)	Z6804196	1
15	*Packing Ring (Set of 2)	H1444196	10
16	Aluminium Washer	-	1
17	Packing Sleeve	-	2
18	Intermediate Sleeve	-	4
19	Outer Sleeve	-	5
20	Packing Flange	-	1
21	Helilock Nut	-	4