


1. Crankcase



No.	Description	Ref. Part No.	QTY
1	Crankcase	1404122780	1
2	Oil Strainer	1615044600	1
3	Copper Washer	0653112400	2
4	Plug	0686420400	1
5	O-Ring	0663987400	2
6	Crankcase Cover	1615172900	1
8	Screw	0144336000	8
9	Cover	1615173000	1
10	Oil dip-stick, Compl.	1612041900	1
11	Rubber, Ring	1612042000	1
12	Flexible Tube	1614098702	1
13	Nut	0584232600	2
14	Ferrule	0584032400	2
15	Ventilation Valve	1614023680	1
16	Copper washer	0653430700	1
17	Nipple	1404052800	1
18	Copper Washer	0653110000	1
19	Suction Chamber	1404198800	1