


## 4. SECOND AND THIRD STAGE AIR CYLINDER ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

## 4. SECOND AND THIRD STAGE AIR CYLINDER ASSEMBLY

No.	Description	Ref Part No.	QTY
1	Cylinder Assembly 2nd Stage (Dia. 160)	1901800821	1
-	Gasket for Door	1901004476	2
-	Inspection Door	1901003348	2
-	Screw	0147135903	20
2	Cylinder Head Assembly (Inner)	1901800822	1
-	Gasket	1901003834	1
-	Paper Gasket	1901003804	4
-	Plug	1901006677	2
-	Plug	1901006305	2
-	Stud	1901002881	4
3	Gasket	1901003804	1
4	Gasket	1901003804	4
5	Cylinder Assembly 3rd Stage (Dia. 85)	1901800837	1
-	Door	1901007650	2
-	Gasket for Door	1901002598	2
-	Screw	0147136203	20
-	Pin	0106228100	1
-	O ring	0663211235	1
6	Cylinder Head Assly. Outer 3rd Stage (Dia. 85)	1901800835	1
-	Flange Plate	1901009520	1
-	Stud (M8 x 40)	1901009522	2
-	Nut M8	0266211000	2
-	Pin	0108129600	1
-	O ring	0663211199	1
-	Soc. Head Screw M12 x 55	0211140603	8
-	Spring Washer	0333217429	8