


8. SECOND AND THIRD STAGE PISTON ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

8. SECOND AND THIRD STAGE PISTON ASSEMBLY

No.	Description	Ref Part No.	QTY
-	Piston Assembly Dia. 160	M000001441	1
1	Piston Half (Dia. 160) Corsshead End	1901010491	1
2	Piston Half (Dia. 160) Nut end	1901012084	1
3	Inserted Ring	1901010493	1
4	Piston Ring Dia. 160	1901000205	3
5	Rider Ring Dia. 160	1901000176	1
6	Piston Rod	1901002591	1
7	Backing Ring	1901008527	1
8	Washer (Spacer)	1901008525	1
9	Flange	1901008520	1
10	Nut	1901002906	8
11	Gasket	0666800035	8
-	Piston Assembly Dia. 85	M000025581	1
12	Piston Rod	1901008519	1
13	Piston Half, Dia. 85 Cross Head End	1901054975	1
14	Piston Half, Dia. 85 Nut End	1901054974	1
15	Piston Ring Dia. 85	1901000011	6
16	Inserted Ring Dia. 85	1901054976	1
17	Rider Ring	1901000012	2
18	Super Bolt Nut	1901000223	1