


# 1. FRAME, CROSS SLIDE, CRANKSHAFT & CONNECTING ROD ASSEMBLY



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

# 1. FRAME, CROSS SLIDE, CRANKSHAFT & CONNECTING ROD ASSEMBLY

No.	Description	Ref Part No.	QTY
1	Frame	B0109162	1
2	Main Bearing	M5480196	3
3	Cover Pump End	C0216162	1
4	Oil Cooler	K0413196	1
5	Top Cover For Frame	A8224196	1
6	Breather	C6110196	1
7	'O' Ring For Breather	H0208170	1
8	Gasket For Top Cover	H1503198	1
9	Cover Oil Pump End	C0225161	1
10	Gasket For Cover	H0751162	1
11	Thrust Washer	B6803196	2
12	Oil Seal Ring	H0302196	1
13	Oil Filter	K0601172	1
14	Cross Head	B1806196	2
15	Crankshaft Assembly	Z1815196	1
16	Gasket For Cover Flywheel End	H0749196	1
17	Cross Head Pin	C9515196	2
18	Cross Slide	B0610196	1
19	Connecting Rod Assembly	Z1814196	2
20	Connecting Rod Bolt	D3037196	4
21	Small End Bush	C9516196	2
22	Big End Bearing (Pair)	C9926196	2
23	Castle Nut	M2225170	4
24	Split Pin	M5105170	4
25	Gasket For Door	H1510198	2
26	Oil Pump Assembly	Z9361196	1
27	Gasket For oil Filter	H1508198	1
28	Cross Head Nut	M2065196	2
29	Internal Circlip	M4008196	4

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.