

**Aftermarket Non-Genuine Replacement
Spare Parts For Ingersoll Rand Air Compressor
Model : Type 30, ESV, ESH, PHE, IHE, XLE-Lub & Non-Lub**



AN ISO 9001 : 2008 CERTIFIED CO.

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time , the illustration and specifications are subject to change without notice.

Aftermarket Non-Genuine Replacement Spare Parts For Ingersoll Rand Air Compressor Type 30 Model

Single & Two Stage Air Compressor

242, 234, 253, 71T2

15T, 30T, 25T2

2340, 2475, 2540, 2545

7100, 3000

Multi Stage High Pressure Air Compressor

231, 7T2, 15T2

Single & Two Stage Vacuum Pump

7V, V235, V244, V255

7VT, V235T, V244T, V255T



Crankshaft | Connecting Rod | Bushes | Service Kit | Valve Assembly | Cylinder | Gasket Kit | Piston | Air Filter Element | Intercooler Tube | Oil Seal | Ring Set | Valve Gasket Kit | Bearing / Connecting Rod Kit | Ring Gasket Kit | Spacer Plate | Stop Plate | Tune up Kit | Flywheel | Piston Assembly | Check Valve | Crankpin Bushing | Safety Valve | Valve Damper | Valve Seat | Pilot Valve | Finger Valve | Crankcase.

**Aftermarket Non-Genuine Replacement Spare Parts For Ingersoll Rand Air Compressor
Model : ESV, ESH, PHE, IHE - Lubricated & Non Lubricated**

ESV & ESH Models – Lub & Non-Lub

7 x 5, 8 x 5, 9.5 x 5,
8 x 7, 9.5 x 7, 11 x 7,

PHE – Lub & Non-Lub

10 & 5 x 7, 12 & 5 x 7, 12 & 7 x 7,
16 & 10 x 7,
14 & 6 x 9, 17 & 9 x 9, 17 & 9 & 4.5 x 9,
12 & 5 & 4 x 7, 12 & 7 & 5 x 7,

IHE – Lub & Non-Lub

12 & 6.5 x 7 IHE -2 NL2,
12 & 7 x 7 IHE-5 NL,
12 & 12 x 7 IHE-NL,
16 & 9B x 7 2IHE-2NL-2,



Valve Assembly | Crankshaft | Port Plate | Valve | Piston Ring Unloader | Oil Pump | Ring & Spring | Connecting Rod | Channel & Spring Set | Valve Seat | Stop Plate Inlet | Plate Seat | Holder guide | Crab Discharge | Discharge Valve | Inlet Valve | FAU Complete | Unloader Cage | Unloader Plunger | Piston Ring | Wearing Ring | Scrapper Ring | Packing Ring | Seat Valve | Wear Strip | Balance Flow.

**Aftermarket Non-Genuine Replacement Spare Parts For Ingersoll Rand Air Compressor
Model : XLE - Lubricated & Non Lubricated**



XLE Models – Lub & Non-Lub

- 14 1/2" - 9" x 7", 16" - 9" x 7",
- 16" - 10" x 7", 17" - 10" x 7",
- 18 1/2" - 11 1/2" x 8 1/2",
- 19" - 11 1/2" x 8 1/2",
- 20 1/2" - 11 1/2" x 8 1/2",
- 20 1/2" - 12 1/2" x 8 1/2",
- 21 1/2" - 12 1/2" x 8 1/2",
- 22" - 13 1/2" x 10",
- 24 1/4" - 13 1/2" x 10",
- 24 1/4" - 14 1/2" x 10",
- 25" - 14 1/2" x 10",
- 26" - 14 1/4" x 10",
- 28" - 16" x 10" XLE-2,

Cylinder Head | Cylinder | Connecting Rod | Piston Rod | Cross Head | Port Plate | Discharge Valve | Inlet Valve | FAU Complete | Valve Cover | Unloader Cage | Unloader Plunger | Piston Ring | Wearing Ring | Scrapper Ring | Packing Ring | Seat Valve Inlet | Wear Strip | Balance Flow.

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Improvement are made from time to time, the illustration and specifications are subject to change without notice.

Division of :

Vikay Mining Equipments

2/5 Vyas Wadi, Dadabhai Road, Vile Parle (West), Mumbai - 400 056. INDIA.

Tel. : +91 - 22 - 2623 7205 / 2624 3729 Fax : +91 - 22 - 2671 6507 / 2671 9985

Email : vkmining@vsnl.com / vkmining@gmail.com

Website : www.partsforcompressor.com

