8. SUCTION VALVE ASSEMBLY
(For HX2T-50/60NP/D)



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the Illustration and specifications are subject to change without notice.

8. SUCTION VALVE ASSEMBLY
(For HX2T-50/60NP/D)

No.	Description	Ref Part No.	QTY
Suction Valve Assembly - First Stage - Qty.: 04 nos. per Compressor			
-	**Suction valve Assembly (First Stage)**	**1903254090**	1
1	*Valve Seat Assembly	Z2544150	1
2	*Valve Keeper	C6176150	1
3	*Damper Plate	1903222605	1
-	**Valve Service Kit**	**1903005195**	1
4	*Valve Plate	1903222505	1
5	*Spring Plate	1903222705	2
6	*Lift Washer	1903074707	2
7	*Split Pin	1903510813	1
-	*'O' Ring for Unloading Piston	1903021008	1
-	*'O' Ring for Valve Cover	1903021208	1
-	*Copper Gasket	1903073808	1
-	Cylinder D 35	1901004020	1
-	Pistion for Regulation	1903090202	1
-	Spring for Lifter	1903347708	1
-	Protection Grill	1901003847	1
Suction Valve Assembly - Second Stage - Qty.: 02 nos. per Compressor			
-	**Suction valve Assembly (Second Stage)**	**1903254290**	1
1	*Valve Seat Assembl	Z2544150	1
2	*Valve Keeper	C6176150	1
3	*Damper Plate	1903222605	1
-	**Valve Service Kit**	**1903005395**	-
4	*Valve Plate	1903222505	1
5	*Spring Plate	1903222705	3
6	*Lift Washer	1903074708	2
7	*Split Pin	1903510813	1
-	*'O' Ring for Unloading Piston	1903021008	1
-	*'O' Ring for Valve cover	1903021208	1
-	*Copper Gasket	1903362213	1
-	Cylinder D 35	1901004020	1
-	Pistion for Regulation	1903090202	1
-	Spring for Lifter	1903347708	1
-	Protection Grill	1901003847	1

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the Illustration and specifications are subject to change without notice.

www.partsforcompressor.com